



CARE INSTRUCTIONS

HOW TO MAINTAIN YOUR TABLETOPS

Laminate Tops

Clean with a soft non-abrasive cloth, sponge or similar material, dry or damp. Clean the laminate surface regularly and mild soap. Always rinse the surface then dry with blotting paper to avoid any residue marks. Do not use abrasive compounds and cleansing agents which have strong acids or salts, and do not use cleaners used for steel or ovens. Always keep the tops dry as the moisture is hard on the chipboard core.

Wood or Veneer Tops

Clean with a soft cloth and furniture polish. Do not use cleaners, solvents or abrasive compounds. Possible liquid or other leftover substances should be removed immediately to avoid absorption.

Natural Stone Product

Clean with a damp cloth and warm water. Do not use cleaners or solvents. Even if treated against the stain, possible liquid or other left-over substances should be immediately removed to avoid absorption. Natural stone has irregularities, same color or surface alterations may be considered a normal feature of the material.

HOW TO MAINTAIN TABLE BASES AND CHAIR FRAMES

Stainless Steel

Cleaning stainless steel will prevent corrosive particles from building up. In environments with salt or chlorine, a weekly cleanse with water and liquid detergent will prevent this. Be sure to dry the surface to prevent particle buildup. For scratches, you can buff out scratches with scotch-brite pads or a very fine grit sandpaper. When you buff the scratches, follow the direction of the surface of the grain.

Powder Coat Bases

Use mild soap and water. All powder coated products should be cleaned with either a soft cloth or a brush, using a solution of mild soap and warm water. The best type of soap to use for this purpose is one that has emulsifiers that can break down the most common types of stains. Exposed surfaces of powder coated products that are deemed the most critical should be cleaned regularly (on either a weekly or a bi-weekly schedule). These can be wiped down and rinsed with filtered water.

Chrome Bases

Use a soft cloth or sponge with warm water and liquid dish detergent. After cleaning, dry with a soft cloth. Use standard furniture polishes to shine chrome.



CARE INSTRUCTIONS

HOW TO MAINTAIN YOUR ERG CHAIRS

Poly & Nylon Shells

Clean with a damp cloth and warm soapy water. Mild cleaners or solvents are acceptable and will not harm plastic materials. It is recommended to dry with a soft cloth until all moisture is gone.

Wood Chairs

Clean with a damp cloth and warm soapy water. Mild cleaners or solvents are NOT recommended as all ERG stains, lacquers and sealers are water-base products. It is recommended to dry with a soft cloth until all moisture is gone.

Upholstered Product

Most fabrics and vinyl's can be cleaned with a damp cloth and warm soapy water. Mild cleaners are acceptable and will not harm plastic fabrics, however, please consult textile manufacture of exact cleaning instruction.